

- 1. Cut the pipe squarely at one of the '^' marks using recommended pipe cutters and ensure the pipe end is free from burrs.
- 2. Insert a Hep₂O SmartSleeve[™] pipe support sleeve into the pipe end.
- 3. Push the pipe firmly into the fitting,
- 4. Use Hep₂O's unique In4Sure[™] joint recognition technology to 'feel' if the pipe is fully inserted. Tug back on the pipe to ensure the grab-ring engages correctly and prevents the pipe withdrawing.
- Clip the HepKey[™] round the pipe next to the joint to be demounted, with the flat side of the HepKey[™] away from the fitting.
- 6. Slide the HepKey[™] up to the fitting and press so that the protruding 'lugs' depress the inner release ring of the fitting. Withdraw the pipe from the fitting.

